



| | | | | |
|---|--|--|---|---|
| <p>Power line</p> <p>Red P+ Blk P- A C</p> | <p>Lock wire</p> <p>Red VCC</p> | <p>Hall sensor</p> <p>NA P+ 5V Signal HA Signal HB</p> | <p>handle</p> <p>P+ 4.3V P- GND Signal SD</p> | <p>Return</p> <p>Signal DC</p> |
| <p>footbrake</p> <p>Signal SL</p> | <p>Speedometer</p> <p>VCC P+ Signal VB</p> | <p>Voice</p> <p>P+ P- Signal TXD</p> | <p>Alarm power</p> <p>P- P+</p> | <p>Alarm signal</p> <p>lock wire VCC Signal C</p> |
| <p>Hand brake</p> <p>black white wire signal SH</p> | <p>Motor forward or reverse</p> <p>Pink wire Signal ZL</p> | <p>General</p> <p>Signal DV GND</p> | <p>strong or soft starting</p> <p>Blue wire GND</p> | <p>Gear</p> <p>Low speed signal K1 High speed signal K2 GND</p> |
| <p>Speed limit</p> <p>White wire Signal F2</p> | <p>Speed limit</p> <p>White wire GND</p> | <p>Signal F2</p> <p>Signal F2 GND</p> | <p>Signal F4</p> <p>Signal F4 GND</p> | <p>Signal A3</p> <p>Signal A3 GND</p> |